

4. Can use the cable clip to fix the cable on the pole.



Took off the plastic cover at the top of the lifting column, insert USK projector tray and adjust for appropiate location then screw it tight.





Model: MB3-170L

Moblie Sit and Stand Desk

Instruction Manual



Cart loading capacity: 55.16LBS/25KG

Hong Kong Zilla Technology Limited

Room 804, Sino Centre 582-592, Nathan Road, Kowloon Hong Kong

Tel: +852-23593168 Fax: +852-27717211

Website: www.zilla-tech.com

The Cart Lable



TIPPING HAZARD!

DO NOT move Cart with Display in highest position.

DO NOT push Cart from front or back of Tower.

DO NOT move Cart over cords or uneven, dirty, soft or sloping surfaces.

DO NOTmove Cart by pushing on Display.

Failure to comply with this caution may result in Cart instability leading to equipmentdamage or personal injury.

TO MOVE CART

- 1. Push Display down to lowest position on Cart.
- 2. Disconnect power cord and attach to Tower.
- 3. Unlock casters; point casters in direction of travel.
- 4. Push Cart from side with hands on Tower.




IMPACT HARZARD!

Be careful the impact!
Moving parts can cause the collision and cut. Do not put the product side or upside down.

Must always keep sticking up. Operation not according to this warning, could lead to a lifting device accidentally move, resulting in serious personal injury and/or property damage.


 Collision danger! The moving parts can cause extrusion and cut. Before you remove the equipment, make sure the workbench face up to the top of the vertical adjustment. Not beaware of this warning may result in serious personal injury and/or property damage. 3. Cart can be locked by pressing the button on caster.





TIPPING HAZARD!

press the button on the top lifting, column it makes the column can adjust.lifting column won't risewithout pressing it.forcing lifting will damage the internal part. 2.Tilt adjustment is +-10 tilt.After adjust for right angle,hand twist the knob manually or using 5mm allen wrench to lock it.



Page 1 Page 10

Adjustment Instruction

 Press the button on the top lifting column, it makes the column can be adjust within 400mm. Button will pop-up while loosing hand and column will lock imidiately can't lifting. (CAUTION: Lifting column won't rise without pressing it. Forcing lifting will damage the internal part.)



Mobile Sit and Stand Desk Model: MB3-175L

Instruction Manual

Images may different from actual product

⚠ Warning:

A warning alerts you to the possibilities of serious injury or death if you do not follow the corresponding instructions. It is installer's responsibility to make sure all components are properly assembled and installed using the instructions provided. Severe personal injury and property damage can result from improper installation or assembly.

▲ Warning:

Do not load Gas Spring Mobile Computer Cart above maximum weight capacities.

Do not mount a display above recommended monitor sizes.

Do not allow children to climb on top of Gas Spring Mobile Computer Cart

Do not move Gas Spring Mobile Computer Cart on sloping surface.

▲ Warning:

It is installer's responsibility to make sure the combined weight of all components does not exceed weight capacity. Exceeding weight capacities can result in severe personal injury or damage to equipment. It is installer's responsibility to make sure the combined weight of all components does not exceed weight capacity of 25KG(55.16LBS).

▲ Warning:

Attachment holes may be damaged if a power drill is used to insert button head cap screws. Screw should be first be inserted and turned by hand with Hexagon key or with screwdriver before using the power drill to complete the attachment.

Read the following warning before installing:

- Verify all parts are included. Do not install if the products or hardware is damage. Not all hardware included will be used.
- This product contain moving parts, Use with caution.
- This product contains small item, keep these items away from children.
- Do not exceed the maximum weight capacity for this product. Exceeding the weight capacity can result in serious personal injury or damage to equipment. Maximum weight capacity is 25KG(55.16LBS).
- -This product is using SUSPA gas spring, warranty period for the gas spring is 3 years.
- -Notspecialized for office use but also suit for office.


Page 9

Specification:


Cart loading capacity:	55.16LBS/25KG
	10°
Desktop Material	E0 class

When the gas spring bearing in excess of the prescribed value, gas spring will decline by $20 \text{ mm}(0.79^{\circ})$.


Supplied Parts



9. Place the wooden tray on the lifting column by using 4MM Allen Wrench.




10.After complete installation,remove the safety screw from bottom of the cart by using 5mm Allen Wrench (Caution: 1.Do not remove the safety screw before complete installation.2.Safety screw should be taken off before adjusting lifting column not will be damaging the internal parts.)





Page 3 Page 8

7. If the LCD or Monitor VESA holes is 200x200, direct using adapter plate screw it.




8. Hook the display on the lifting column. Tighten the Hex Nut M8 corresponding with Washer by using Allen Wrench.






Product Diagram




Page 7

Installation


1. Attached aluminium alloy support to sheet metal base by tightening the flat head screw with allen wrench M4.




2.Using the same way to complete the other side. (Caution: Picture A are the place with pedal locking caster.) The other side without pedal locking caster. After completed, put in the rubber cover.




3. Tightening the lifting column on the centre of the sheet metal base by round head hex screw using allen wrench M5.




4. By putting the rail through suitable columns.



5.Attached the bracket on the universal adapter.Put on washer and screw M6x15mm on the mounting holes.Using Philip screw driver lock it.



6.Attached interface bracket to display with washer and screw on the mounting holes. Tighten with Philip screw driver. Use spacers for recessed mounting holes.



Page 5